

DEVICE SERIAL NO FORMATS

To help you identify VisionTrack devices – here are a list of serial number formats.



VT1000

SERIAL NUMBER: Starts with VIMS



VT2000

SERIAL NUMBER: Starts with V2MS



VT2.2

SERIAL NUMBER: Starts with A2M2




VT3000

SERIAL NUMBER: Starts with 003

VT3000-AI

SERIAL NUMBER: Starts with 002



VT4000

SERIAL NUMBER: Starts with M4TM



VT5500

SERIAL NUMBER: Starts with 00600, 009900 or 009901 (2021 onwards)



VT6.2

SERIAL NUMBER: Starts with 009900 or 009901 (2021 onwards)
(The difference is going to be the front panel)



VT8000

SERIAL NUMBER: Starts with 00800 or 008800



HOWEN (PRODUCT DISCONTINUED)

SERIAL NUMBER: Starts with 007